


SCHÖCK ISOKORB® TYPE QS

Installation instructions for concrete frame contractor


QS

Reinforced concrete-to-steel



SCHÖCK ISOKORB® TYPE QS

Installation instructions for steel fabricators



QS

Reinforced concrete-to-steel